

Basic Western Blot Protocol AKT Tumor

Buffer Solutions:

Running Buffer:

100 ml 10x TRIS/Gly/SDS
900 ml dH₂O

Transfer Buffer:

100 ml 10x TRIS/Gly (40 ml of 25x and 760 dH₂O)
700 ml dH₂O
200 ml methanol

TBS-T:

100 ml 10x TBS
900 ml dH₂O
1 ml Tween 20

Blocking Buffer/Sln: 5% milk in TBS-T

3.5 g dry milk
70 ml TBS-T (100 ml TBS; 900 ml H₂O; 1 ml Tween)

Protocol:

I. Run gel:

1. Prepare samples for loading:
 - a. Add 2x SDS loading buffer to sample at 1:1 (only if sample not already in SDS)
 - b. Heat on heating block (100°) for 5 minutes
2. Use pre-made gel (in 4° behind Ling's bench)
 - a. Remove tape, mark the bottom of wells with black marker for better visualization, and remove the comb (slowly so as not to break wells)
 - b. Load gel in gel box and lock into place
 - c. Fill inner chamber of gel box with running buffer ... look for leaks
 - d. Fill outer chamber ½ way or more
3. Add 10 ul of water to protein standard to resuspend then load (12-15 ul) into well
4. Load samples (max for a 10 well gel is 37 ul per well)

Well	Lysate	Protein #	Lysate Vol	Result
1	Rainbow Marker	--	10ul	
2	Positive Control-K7M2	?	30ul	
3	Cardiac	4.904	24.5	

4	Liver	9.378	12.8	
5	Lung	9.195	13.1	
6	Spleen	11.891	10.1	
7	Kidney	4.475	26.8	
8	Pancreas	4.561	26.3	

5. Let gel run at 120V for 1-1.5 hrs.

II. Transfer to Nitrocellulose membrane

1. Soak red/black transfer block and two sponge sheets in transfer buffer
2. Prepare nitrocellulose membrane sandwich:
 - a. Mark side of the nitrocellulose membrane that will contact gel with special marker (Ling's bench)
 - b. Soak membrane and sandwich paper (x2) in transfer buffer
3. Remove gel from plastic panel, cut bottom just above protein front and at top just below the wells with ruler edge
4. Make Transfer "Sandwich": black on bottom, 1 sponge, 1 piece of sandwich paper, gel, nitrocellulose membrane (marked side down), 1 piece of sandwich paper, 1 sponge, red side on top
5. Place the red/black transfer block in the Owl transblot chamber
 - a. Chamber should have stir bar in the bottom and be connected to the water coolant system next to it
 - b. Black side facing black, red facing red (towards the wall)
 - c. Fill chamber with transfer buffer to cover top of red/black transfer block
6. Run at 300mAmp for 1.5 hr (be sure the transfer gets to 300mAmp, may have to adjust voltage up to reach 280-300 mAmp mark)

III. Block

1. Carefully remove nitrocellulose membrane from red/black block
2. Cut membrane if necessary by staining to visualize desired band locations
 - a. Stain with 0.1% Ponceaus in 5% AAC (premade lab sln)
 - b. Wash excess stain off with dI water
 - c. Cut membrane at desired standard band
 - d. Rinse again in dI water (or TBS-T) to remove excess stain
3. Cover membrane with blocking solution and shake at RT for 1 hr
 - a. 5ml for small container, 10ml for larger container

IV. Primary Anti-body

1. Pour off blocking buffer
2. Cover membrane thoroughly with TBS-T and place on shaker for 5 min. at RT

- repeat for a total of 3 washes
4. Pour primary antibody solution over membrane*
 - a. add 1:1000 Dilution of AKT: 10 ml AKT to 20 mL TBS-T
 5. Shake overnight at 4° or 1 hr RT

V. Secondary Antibody *see antibody sheet to determine if dilute in 5% BSA

1. Pour off and save primary antibody solution (store at 4° in TBS-T)
2. Cover membrane thoroughly with TBS-T and place on shaker for 5 min. at RT
repeat for a total of 3 washes
3. Add secondary antibody and shake at RT for 1 hr
dilution of 1:20,000
 - a. Add 1uL anti-rabbit secondary to 20 mL-T TBS

VI. Exposure

1. Discard secondary antibody
2. Cover membrane thoroughly with TBS-T and place on shaker for 5 min. at RT
repeat for a total of 3 washes
3. Add 4 ml SuperSignal West Pico luminal enhancer and 4 ml SuperSignal West Pico stable peroxide solution to container and shake for 5 min. at RT
*if doing a large number of containers, mix the enhancer and peroxide solution together just before adding to membranes
4. Remove membrane from solution, blot to dry, and wrap in plastic wrap
5. Expose membrane